



High watt resistors should be mounted raised from the PCB on ceramic stand-offs

**Safety First:**  
The clock must never be operated without a ground/earth connection.

psu timebase 04
7/6/20 2:48 AM
Sheet: 2/2

